


Remote Control Function:

1. **CH key:** Set the frequency after selecting the frequency directly by number key. (For example, if you want to tune into the frequency 94.5MHz same as your car radio, select the number key 0945 and press the CH button to confirm.)
2. **FL+ / FL- key:** change the playing folder one by one.
3. **CH+CH- key:** Adjusting the frequency with 0.1MHz by short press, adjusting the frequency quickly by long press.
4. **PREV/NEXT key:** Select previous or next song.
5. **+/- key:** Volume Turn up or Turn down
6. **PLAY key:**
 - Answer the call:** Short press the ►|| key to answer the call when someone calling.
 - Reject the call:** Long press the ►|| key to reject the call when someone calling.
 - Call transfer:** Long press the ►|| key to transfer the call between the unit to your mobile phone when in talking.
 - Last number re-dialing:** Long press the ►|| key to re-dial the last caller number when Bluetooth connected.
7. **Play/Pause:** Short press the ►|| key to play the MP3/WMA (optional) file. To pause during playback, press the ►|| key. To resume, press it again.
7. **Number key:** Select song by figure under normal playing state, select frequency after entering into the frequency state.
8. **Short press EQ key:** Change the playing EQ mode (Rock, Classical, Normal, POP, Jazz, Country)
9. **Long press EQ key:** Select circulation mode. (ALL, SINGLE, FOLDER, NORMAL, RANDOM)

Notice: If this device is along with steering wheel remote control, please refer to the operation instructions as following:

Operations on the steering wheel remote control



Steering remote control:

1. **PREV/NEXT key:** Select previous or next song.
2. **+/- key:** Volume Turn up or Turn down
3. **PLAY key:**
 - Answer the call:** Short press the ►|| key to answer the call when someone calling.
 - Reject the call:** Long press the ►|| key to reject the call when someone calling.
 - Call transfer:** Long press the ►|| key to transfer the call between the unit and your mobile phone when in talking.
 - Last number re-dialing:** Long press the ►|| key to re-dial the last caller number when Bluetooth connected.
4. **Play/Pause:** Short press the ►|| key to play the MP3/WMA (optional) file. To pause during playback, press the ►|| key. To resume, press it again.
4. **Short press EQ key:** Select EQ mode (Rock, Classical, Normal, POP, Jazz)
5. **Long press EQ key:** Select circulation mode. (ALL, SINGLE, FOLDER, RANDOM)


Notice

- For the sake of safety, please insert the USB flash disk or memory card before you plug the device into the car cigar socket.
- The device supports most USB flash disks or memory card except a few.
- If the device cannot read data from USB flash disk or memory card, try to reinsert the USB flash disk/memory card, or reinsert the device into the cigarette lighter socket.
- Frequency of the car FM tuner should be the same as that of the device.
- Do not pull out or insert a USB flash disk or memory card while the device is being powered by the car cigarette lighter. If you want to, remove the device from the socket first and insert or remove the disk or card before you re-power the device.
- The progress may be slow when the USB flash disk or memory card stores too many audio files.
- In order to extend the device life, please do not keep it in use for too long.

Safety Fuse Replacement

When the device cannot work properly, it may due to the safety fuse failure. Please replace the safety fuse following these steps if necessary:

- Remove the device from the cigarette lighter socket.
- Twist the tip of the cigar plug.



Remove the bad safety fuse and insert a new one (Extra in the package)